

# SeeMeCNC Guides

## Step 1. Introduction and Pre-Assembly

There are a few sub-assembly builds that need completed before starting the build. This Pre-Assembly guide will walk you through preparing them.

Written By: SeeMeCNC




## Step 1 — HE280




- HE280 Assembly: [Guide](#)

## Step 2 — Carriage Assembly



- Carriage Assembly: [Guide](#)

### Step 3 — EZR Struder



- EZR Struder Assembly: [Guide](#)

### Step 4 — LCD / Enclosure



- LCD Enclosure Assembly: [Guide](#)

## Step 5 — Wrap-Up



- These Sub-Assemblies will be installed during the build of the Rostock Max v3. Please put them aside until they are call for during the build.
- Proceed to: [Step 2. REV2 Rostock Max v3 Base Assembly](#)